

# HMMA 831 -11

## HARDWARE LOCATIONS FOR HOLLOW METAL DOORS AND FRAMES







This Manual was developed by representative members of and approved by the Hollow Metal Manufacturers Association (HMMA) Division of the National Association of Architectural Metal Manufacturers (NAAMM) to provide their opinion and guidance on the basic design of hollow metal doors and frames. This standard contains advisory information only and is published as a public service by NAAMM and its HMMA Division. NAAMM and its HMMA Division disclaim all liability of any kind for the use, application, or adaptation of material published in this standard.

Purchasers of NAAMM Standards may receive current information on all NAAMM Standards by calling or writing the National Association of Architectural Metal Manufacturers.

National Association of Architectural Metal Manufacturers

800 Roosevelt Road Bldg. C, Suite 312 Glen Ellyn, Illinois 60137 Phone: (630) 942-6591 Fax: (630) 790-3095 www.naamm.org

Copyright © 1997, 2011 National Association of Architectural Metal Manufacturers All Rights Reserved

### RECOMMENDED HARDWARE LOCATIONS FOR HMMA HOLLOW METAL DOORS AND FRAMES

These standards are recommended by the Hollow Metal Manufacturers Association as representing the long accepted usual preferences of both architects and users under normal conditions of use. Under some circumstances these standard locations are inadvisable for certain items based on accessibility codes. For example, a lower position for the deadlock is possible, when intended usage by small children or handicapped persons necessitates require positioning the user handled items in other than these recommended standard locations.

#### Hardware location and floor conditions

As shown on the drawing, all hardware items except the upper and intermediate hinges are located by fixed dimensions from the floor to the centerline of the item, making the locations of all user-handled items at the same level for all door heights. The floor is defined as top of the concrete or structural slab. Refer to HMMA-810 TN01-03 "Defining Undercuts" when determining hardware locations based on special floor conditions.

#### **BUTT HINGE**

The three hinges shown on the drawing are recommended for doors over 5 ft. 0 in. (1524 mm) and including 7 ft. 6 in. (2286mm) in height. For doors of greater heights, where four or more hinges are used, the top and bottom hinges are located as shown, with the intermediate hinges being equally spaced between them. The hinge backset (the dimension from the stop face, or narrow side, to the edge of the hinge cutout) is 1/4 in. (6.4mm).

#### LOCKSET

Regardless of the type of lock or latch used, the centerline of the lever or knob is located at the 38 in. (965mm) from the floor, for the convenience of the user. This will result in some variation in the strike location, depending on the type of lock used.

#### EXIT DEVICE

Locations may vary depending on hardware manufacturers' recommended locations or as required by code.

#### AUXILLIARY DEADLOCK AND LATCH

The recommended location for the deadlock is 46 in. (1168mm) to centerline positioning it so as to avoid interference with through bolts and preparations for other hardware. ADA requires that the centerline of operating element of cylinder be no more than 48 in. (1219 mm) above floor.

#### **PUSH-PULL HARDWARE**

The recommended location for the center of the grip on a door pull or on a push plate, and the centerline of a push/pull bar is 46 in. (1168mm).

#### **ROLLER LATCH**


The recommended location is 46 in. (1168 mm) to centerline of latch. Roller latches are generally used with dummy knobs or with push/ pulls.

#### **HOSPITAL LATCH**

The recommended location is 45 in. (1143 mm) to the centerline of latch.

#### DOOR CONTROL DEVICES (CLOSERS, HOLDERS, STOPS, OPERATORS)

Locations may vary depending on hardware manufacturers' recommended locations or as required by code.



#### **RECOMMENDED GUIDE SPECIFICATIONS FOR HMMA HOLLOW METAL DOORS AND FRAMES**

HMMA 860 — Hollow Metal Door and Frames

ANSI/NAAMM HMMA 861 — Commercial Hollow Metal Doors and Frames

ANSI/NAAMM HMMA 862 — Commercial Security Hollow Metal Doors and Frames

ANSI/NAAMM HMMA 863 — Detention Security Hollow Metal Doors and Frames

ANSI/NAAMM HMMA 865 — Swinging Sound Control Hollow Metal Doors and Frames

ANSI/NAAMM HMMA 866 — Stainless Steel Hollow Metal Doors and Frames

ANSI/NAAMM HMMA 867 — Commercial Laminated Core Hollow Metal Doors and Frames

#### **RELATED HMMA DOCUMENTS**

- HMMA 800 Introduction to Hollow Metal
- HMMA 801 Glossary of Terms for Hollow Metal Doors and Frames
- HMMA 802 Manufacturing of Hollow Metal Doors and Frames
- HMMA 803 Steel Tables
- HMMA 805 Recommended Selection and Usage Guide for Hollow Metal Doors and Frames
- HMMA 810 Hollow Metal Doors
- HMMA 820 Hollow Metal Frames
- HMMA 830 Hardware Selection for Hollow Metal Doors and Frames
- HMMA 831 Recommended Hardware Locations for Hollow Metal Doors and Frames
- HMMA 840 Installation and Storage of Hollow Metal Doors and Frames
- HMMA 841 Tolerances and Clearances for Commercial Hollow Metal Doors and Frames
- HMMA 850 Fire-Rated Hollow Metal Doors and Frames
- HMMA 890 Technical Summary
- HMMA 810-TN01 Defining Undercuts
- HMMA 820-TN01 Grouting Hollow Metal Frames
- HMMA 820-TN02 Continuously Welded Frames
- HMMA 820-TN03 Guidelines for Glazing Hollow Metal Transoms, Sidelights and Windows
- HMMA 840-TN01 Painting Hollow Metal Products
- HMMA 840-TN02 Maintenance of Installed Hollow Metal Products