

# Guidelines to Measure for Replacement Doors in Existing Frame Openings



Standards As Tough As Steel.™  
© 2019 Steel Door Institute

**STEEL DOOR INSTITUTE**  
30200 DETROIT ROAD • CLEVELAND, OHIO 44145

# Guidelines to Measure for Replacement Doors in Existing Frame Openings

## 1 Introduction

This document is intended to provide guidance for measurement and recording of existing opening and/or door dimensions required to fully detail a replacement door(s). The included figures identify the basic dimensions of frame openings and doors with standard hardware applications. Separate illustrations are provided for detailing single and paired frame openings as well as detailing individual doors.

### 1.1 Referenced Documents

Related SDI Technical Series documents provide additional technical guidance on this topic:

SDI-108 *Recommended Selection and Usage Guide for Standard Steel Doors*

SDI-111 *Recommended Details for Standard Steel Doors, Frames, Accessories and Related Components*

SDI-122 *Installation Troubleshooting Guide for Standard Steel Doors and Frames*

SDI-129 *Hinge & Strike Spacing*

SDI-134 *Glossary of Terms for Hollow Metal Doors and Frames*

### 1.2 Other Reference Materials

ANSI/BHMA A156.1-2016 *Butts and Hinges*

ANSI/BHMA A156.7-2014 *Template Hinge Dimensions*

ANSI/BHMA A156.115-2014 *Hardware Preparation in Steel Doors or Steel Frames*

### 1.3 Notes

#### 1.3.1 Tolerances

All values which do not carry specific tolerances or are not marked maximum or minimum shall have the following tolerances: Linear dimensions shall be  $\pm 1/16$  in. (1.6 mm). Weight or force shall be  $\pm 2\%$ . Angles shall be  $\pm 2$  degrees. Where only minus tolerances are given, the dimensions are permitted to be exceeded at the option of the manufacturers.

#### 1.3.2 Gauge vs. Thickness

While the term 'gauge' is no longer common for defining material thickness it is still used to specify doors and frames for ordering purposes. The term 'thickness' is used when defining the actual dimension of an item,

and the term 'gauge' is used in the context of specifying a particular door or frame.

## 2 Preparation

Installation conditions and issues will affect door operation and should be considered beforehand. Door and hardware in an improperly installed frame may function poorly. Check the floor clearance and the frame opening to verify acceptable square and level conditions. Reference SDI-122 to check for frame installation issues. Slight adjustment may be possible without removal. **Note:** Frame may need to be replaced for proper function of the opening.

Basic door and frame terminology used in instructions and illustrations is explained in more detail below and in SDI-134.

The term "nominal dimensions" refers to the width and height dimensions of the frame opening. When applied to a door size, it is implicit that the door is undersized to properly fit into the nominal frame opening with proper clearances. The term "net dimension" refers to the door's width and height dimensions. To illustrate, the door width and height dimensions in (Fig 3) are actual or "net" dimensions.

Technical Data Series SDI-129, "Hinge and Strike Spacing," provides standard locations for hinge and strike preparations in SDI member doors and frames. Manufacturers' locations may change so it is imperative that the hinge and strike locations be measured for replacement doors and frames.


Hardware preparations of the replacement door must be sized and located to coincide with those on the existing frame to ensure proper fit, positioning and clearances for door operation.

For hardware applications not covered below, contact the replacement door or hardware manufacturer.

## 3 Measurements

### 3.1 Tools

- Tape measure
- Steel rule
- Calipers (optional)
- Framing square and small square
- Level (24" minimum)
- Plumb bob (optional)



-	Opening #	
A	Handing	
B	Opening Width (Min)	
C	Opening Height (Min)	
D	Hinge Size	
E	First Hinge	
F	Second Hinge	
G	Third Hinge (if 4)	
H	Fourth Hinge	
J	Hinge Backset	
K	Hinge Weight	
L	Strike Size	
M	Top of Strike	
N	C/L Strike Hole	
O	Threshold Height	
P/Q	Sill Condition	
R	Door Thickness	
S	Door Rabbet	
T	Stop Height	
U	Label Requirements	

All Measurements  $\pm 1/32"$   
 All Measurements are of Existing Frame






Figure 1 – Existing Frame Opening – Single Door

## 4 Frame Opening Measurements

4.1 The included illustrations provide guidance as follows:

- Figure 1 – frame opening dimensions for single door installation
- Figure 2 – hinge weights
- Figure 3 – frame opening dimensions for door pair installation
- Figure 4 – actual door dimensions
- Figure 5 – multiple frame openings worksheet

4.2 Frame opening width and height. These dimensions are to be taken from rabbet-to-rabbet surfaces. It is recommended that dimensions of both width and height be taken at three locations and the smallest of these measurements be used for sizing of the door.

4.3 Frame profile rabbet. The door thickness must be matched to this frame dimension. It is important that you have this dimension especially if you do not have the door.

**Example** – standard 1-3/4" thick door is used with 1-15/16" wide rabbet

4.4 Threshold height (if existing or planned) from the floor. Door undercut may need to be adjusted to allow clearance for thresholds.

4.5 Openings may have certification requirements such as fire ratings. Such requirements should be indicated by labels attached to the door (and sometimes frame). These label requirements should be noted and recorded on the form.

## 5 Frame Hardware Measurements

### 5.1 Hinge Height

The height of the hinge leaf. The most common hinge height (size) is 4-1/2", then 5", followed by 3-1/2", 4" and 6", then other sizes.

### 5.2 Hinge Weight

The hinge leaf thickness. Hinge mortise depth normally corresponds to this individual hinge leaf thickness. Please note that special applications exist for "double-mortise" and "surface applied". For 4-1/2" hinge size, standard weight is 0.134" and heavy weight is 0.180". Standard and heavy weight vary by hinge size as shown in Figure 2, a table adapted from ANSI/BHMA A156.1. Additional hinge details are provided in A156.7 for hinge templating and A156.115 for door preps.

### 5.3 Hinge Backset

The distance from the edge of the applied hinge leaf to the frame stop. This is a critical measurement and must be accurate within 1/32". The most common dimension is 5/16". The hinge backset on the door will be properly adjusted from this measurement (typical - 1/16") to ensure proper clearance.

### 5.4 Hinge Locations

The vertical location of each hinge cutout. The recommended method of measurement is from the door rabbet surface of the existing frame head to the top of each hinge (i.e. "top-to-top").

### 5.5 Strike Height

Vertical dimension of the frame strike cutout. The most common is 4-7/8", followed by 2-3/4" then 3-1/2".

Hinge Height +0/-0.015 in	Grade 1			Grade 2	Grade 3	Grade 4
	Triple Weight	Double Weight	Heavy Weight	Standard Weight		Light Weight
	Thickness of Metal Inches +/-0.005 in.					
3"	–	–	–	–	–	>0.077
3-1/2"	–	–	–	0.123	0.123	>0.085
4"	–	–	–	0.130	0.130	>0.085
4-1/2"	–	–	0.180	0.134	0.134	–
5"	–	–	0.190	0.146	0.146	–
6"	–	–	0.203	0.160	0.160	–
8" (not in A156.1)	–	–	0.203	–	–	–

Figure 2 – Hinge Weights (adapted from ANSI/BHMA A156.1)

## 5.6 Strike Location

While commonly specified from the floor (bottom of frame) to centerline C/L of cutout in new installation, the recommended measurement for replacement doors is from the door rabbet surface of the frame head to the top of the cutout (top-to-top).

## 6 Additional Measurements for Paired Opening

Paired openings add a variety of latching options for both active and inactive doors, particularly devices that latch vertically into strikes located in the frame head and floor/sill/threshold. If device strikes mortised into either the frame head or the floor/sill/threshold and are intended to be re-used, it becomes important to note their size and centerline (C/L) of engagement. These dimensions may restrict replacement hardware options. Strike plates are indicated on the illustrations for the “Existing Frame Openings - Paired Openings” as dimensions S.1, S.2, T.1 & T.2. Consult replacement door manufacturer if moving surface-mounted strikes is necessary.

## 7 Door Measurements

### 7.1 Door width

Dimensions taken from edge to edge across the door using steel tape. On doors with beveled edges, measurements should be taken from the wide side of the door, noting whether beveled on lock, hinge or both edges. For doors of door pairs, application or absence of an astragal affects door width.

### 7.2 Door Height

Dimensions taken from top to bottom edges of door using a steel tape.

### 7.3 Door Thickness

Dimension of door thickness using steel tape or caliper.

While the term ‘gauge’ is no longer common for defining material thickness it is still used to specify doors and frames for ordering purposes. As such, the terms ‘thickness’ is used when defining the actual dimension of an item and ‘gauge’ is used in the context of specifying a particular door or frame.

## 8 Door Hardware Measurements

### 8.1 Hinge Height

The height of the hinge leaf. The most common hinge height (size) is 4-½”, then 5”, followed by 3-½”, 4” and 6” then other sizes. Note: hinge width does not impact frame hardware measurement.

### 8.2 Hinge Weight

The hinge leaf thickness. Hinge mortise depth normally corresponds to this individual hinge leaf thickness where 0.134” is the most common (standard weight), followed by 0.180” (heavy-weight), then other less common thicknesses. Please note that special applications may exist for “double-mortise” and “surface applied” hinge mortises.

### 8.3 Hinge Backset

The distance from the edge of the applied hinge leaf to the door face nearest the frame stop. This is a critical measurement and must be accurate within ⅛”. The most common dimension is ¼”.

### 8.4 Hinge Locations

The vertical location of each hinge cutout. The recommended method of measurement is from the top of the door to the top of each hinge (i.e., “top-to-top”).

### 8.5 Latch Dimension

The width and height of the latch plate on the edge of the door. The most common are cylindrical (1-⅛” x 2-¼”) and mortise (1-⅛” x 8”).

### 8.6 Latch or Lock Location

Commonly specified from the floor (bottom of frame) to centerline (C/L) of cutout in edge of door or centerline (C/L) of strike in new installation. The recommended measurement for replacement doors is from the top of the door to the top of the cutout in edge of door if applicable or top of door to centerline (C/L) of latch actuating hole (i.e., “top-to-top”).

### 8.7 Lock Backset

The horizontal dimension from the door edge to the centerline (C/L) of the latch actuating hole on face of door. The most common backset dimension is 2-¾” for cylindrical and mortise locks. Doors with beveled lock edges should be measured from the wider beveled side.

## 9 Door Accessories


**Note:** Instructions vary by accessory manufacturer and replacement door manufacturer.

### 9.1 Glass kits / inserts

**9.1.1** Measure from top of door to top of cutout, top of outside edge of insert, or top of visible glass.

**9.1.2** For locating off centered inserts; measure from lock edge of door to edge of cutout; outside edge of insert; edge of visible glass.

**9.1.3** Exposed glass size – specifies the resulting visible glass area shown once installed.



-	Opening #	
A	Handing	
B	Opening Width (Min)	
C	Opening Height (Min)	
D	Hinge Size	
E	First Hinge	
F	Second Hinge	
G	Third Hinge (if 4)	
H	Fourth Hinge	
J	Hinge Backset	
K	Hinge Weight	
L	Threshold Height	
M/N	Sill Condition	
N	C/L Strike Hole	
O	Door Thickness	
P	Door Rabbet	
Q	Stop Height	
S.1	Head Strike C/L	
S.2	Head Strike C/L	
S.3	Head Strike Type	
T.1	Floor Strike C/L	
T.2	Floor Strike C/L	
U	Label Requirements	

Recommended to verify that hinge locations are the same on both hinge jambs of Double Openings.

Measurements S and T locate mortised or surface-applied strikes in the frame header or floor / threshold.

All Measurements  $\pm 1/32"$   
All Measurements are of Existing Frame






Figure 3 – Existing Frame Opening – Door Pair

**Note:** If Glass Light or Louver is Required, Specify Location Dimensions on Door Elevation with Exposed Glass Size or Louver Size.

**Note ①**


If Door Has Beveled Edges, Measure The Wide Side For Actual Door Width



Qty Req'd \_\_\_\_\_ Mark Number \_\_\_\_\_ Label Req'd \_\_\_\_\_

**A Hand of Door**

- LH  RHR
- RH  LHR



**B Door Thickness**

- 1-3/4"  1-3/8"

**C Material**

- 20 GA  COLD ROLLED
- 18 GA  GALVANIZED
- 16 GA  STAINLESS
- 14 GA

Fill in all dimensions



Respond to all



**D Lock Provisions**

- CYL. GOV'T. 161 - 1-1/8" x 2-1/4" EDGE
- MORTISE EDGE - 1-1/4" x 8"
- BLANK - NO CUTOUT
- DEADLOCK - 1-1/8" x 2-1/4" EDGE
- PANIC :  RIM  VERTICAL ROD  CONCEALED

**E Hinge Provisions**

- 3-1/4"  STD. WGT.
- 4-1/4"  HEAVY WGT.
- 5"  \_\_\_\_\_

**F Closer Reinforcements**

- REQUIRED  NOT REQUIRED

**G If Inactive Leaf:**

- ASTRAGAL  NO ASTRAGAL (WIDTH + 3/32")
- FLUSH BOLTS

OTHER \_\_\_\_\_

**Figure 4 – Replacement Door Details**

## 9.2 Louvers

**9.2.1** Measure from top of door to either top of cutout or top of outside edge of insert

**9.2.2** For locating off centered inserts, measure from lock edge of door to edge of cutout; outside edge of insert.

## 10 Replacement Door Details

Existing frame opening dimensions should coincide with door measurements plus proper clearances. Basic options of door construction, hardware and accessories (door gauge and finish, glass kits dimensions and location, lock provisions, closer reinforcements and astragals on pairs) are listed on Figure 4.

-	Opening					
A	Handing					
B	Opening Width					
C	Opening Height					
D	Hinge Size					
E	First Hinge					
F	Second Hinge					
G	Third Hinge (if 4)					
H	Fourth Hinge					
J	Hinge Backset					
K	Hinge Weight					
L	Strike Size					
M	Top of Strike					
N	C/L Strike Hole					
O	Threshold Height					
P / Q	Sill Condition					
R	Door Thickness					
S	Door Rabbet in Frame					
T	Frame Stop Height					
U	Label Requirements					

Refer to Measuring Directions for guidance on where and how to measure existing frames.

**Figure 5 – Existing Frame Measurement – Single Door – Multiple Openings**



---

## AVAILABLE PUBLICATIONS

---

### Specifications

- ANSI/SDI A250.6** Recommended Practice for Hardware Reinforcing on Standard Steel Doors and Frames
- ANSI/SDI A250.8** Specifications for Standard Steel Doors and Frames (SDI-100)
- SDI-108** Recommended Selection & Usage Guide for Standard Steel Doors
- SDI-118** Basic Fire Door, Fire Door Frame, Transom/Sidelight Frame, and Window Frame Requirements
- SDI-128** Guidelines for Acoustical Performance of Standard Steel Doors and Frames
- SDI-129** Hinge and Strike Spacing
- SDI-133** Guideline for Specifying Steel Doors & Frames for Blast Resistance

### Test Procedures

- ANSI/SDI A250.3** Test Procedure & Acceptance Criteria for Factory Applied Finish Coatings for Steel Doors and Frames
- ANSI/SDI A250.4** Test Procedure & Acceptance Criteria for Physical Endurance for Steel Doors, Frames and Frame Anchors
- ANSI/SDI A250.10** Test Procedure & Acceptance Criteria for Prime Painted Steel Surfaces for Steel Doors and Frames
- ANSI/SDI A250.13** Testing and Rating of Severe Windstorm Resistant Components for Swinging Door Assemblies for Protection of Building Envelopes (Not applicable for FEMA 320/361 or ICC-500 Shelters)
- SDI-113** Standard Practice for Determining the Steady-State Thermal Transmittance of Steel Door and Frame Assemblies
- SDI-131** Accelerated Physical Endurance Test Procedure for Steel Doors

### Construction Details

- ANSI/SDI A250.11** Recommended Erection Instructions for Steel Frames
- SDI-110** Standard Steel Doors & Frames for Modular Masonry Construction
- SDI-111** Recommended Details for Standard Steel Doors, Frames, Accessories and Related Components
- SDI-122** Installation Troubleshooting Guide for Standard Steel Doors & Frames

### Miscellaneous Documents

- SDI-112** Zinc-Coated (Galvanized/Galvannealed) Standard Steel Doors and Frames
- SDI-117** Manufacturing Tolerances for Standard Steel Doors and Frames
- SDI-124** Maintenance of Standard Steel Doors & Frames
- SDI-127** Industry Alert Series (A-L)
- SDI-130** Electronic Hinge Preparations
- SDI-134** Glossary of Terms for Hollow Metal Doors and Frames
- SDI-135** Guidelines to Measure for Replacement Doors in Existing Frame Openings

---

## MEMBERS OF THE STEEL DOOR INSTITUTE

---

### **CECO**

**AN ASSA ABLOY DOOR GROUP COMPANY**  
9159 Telecom Drive  
Milan, TN 38358-3425  
(731) 686-8345  
[www.cecodoor.com](http://www.cecodoor.com)

### **CURRIES**

**AN ASSA ABLOY DOOR GROUP COMPANY**  
1502 12th Street, P.O. Box 1648  
Mason City, IA 50402-1648  
(641) 423-1334  
[www.curries.com](http://www.curries.com)

### **DEANSTEEL MANUFACTURING CO.**

931 S. Flores Street  
San Antonio, TX 78204-1406  
(210) 226-8271  
[www.deansteel.com](http://www.deansteel.com)

### **DCI**

7980 Redwood Avenue  
Fontana, CA 92336-1638  
(909) 770-5700  
[www.doorcomponents.com](http://www.doorcomponents.com)

### **HOLLOW METAL XPRESS**

602 S. 65th Avenue  
Phoenix, AZ 85043  
(623) 936-7000  
[www.HMXpress.com](http://www.HMXpress.com)

### **MESKER DOOR, LLC**

3440 Stanwood Boulevard  
Huntsville, AL 35811-9021  
(256) 851-6670  
[www.meskerdoor.com](http://www.meskerdoor.com)

### **MPI**

319 North Hills Road  
Corbin, KY 40701  
(606) 523-0173  
[www.metalproductsinc.com](http://www.metalproductsinc.com)

### **PIONEER INDUSTRIES, INC.**

**AN ASSA ABLOY DOOR GROUP COMPANY**  
111 Kero Road  
Carlstadt, NJ 07072  
(201) 933-1900  
[www.pioneerindustries.com](http://www.pioneerindustries.com)

### **PREMIER STEEL DOORS & FRAMES**

2840 Sterlington Road  
Monroe, LA 71203  
(318) 361-0796  
[www.trustpremier.com](http://www.trustpremier.com)

### **REPUBLIC DOORS & FRAMES**

155 Republic Drive  
McKenzie, TN 38201-0580  
(731) 352-3383  
[www.republicdoor.com](http://www.republicdoor.com)

### **SMP**

**AN ASSA ABLOY DOOR GROUP COMPANY**  
5678 Concours Street  
Ontario, CA 91764  
(909) 593-2100  
[www.secmet.com](http://www.secmet.com)

### **STEELCRAFT**

9017 Blue Ash Road  
Cincinnati, OH 45242  
(513) 745-6400  
[www.steelcraft.com](http://www.steelcraft.com)



Standards As Tough As Steel.™

---

# STEEL DOOR INSTITUTE

---

30200 DETROIT ROAD • CLEVELAND, OHIO 44145  
440.899.0010 • FAX 440.892.1404 • [www.steeldoor.org](http://www.steeldoor.org)